



2650-1869-77

1967-68 CAMARO / FIREBIRD ALUMINUM BILLET ALUMINUM GAUGE MOUNTING SYSTEM INSTALLATION INSTRUCTIONS (5" AUTO METER "SUPER BEZELS")

Model 7056

Included hardware:

- Four 10-32 x 1" machine screws
- One 10-32 x 3/8" machine screw
- Three 8-32 x 1/2" F-type self tapping screws
- Two # 6 x 1/2 sheet metal screws
- Two 1/8" step Z-clips
- Two O-rings

1. Remove the stock bezel from your vehicle.
2. The screw retainer clips that are located on the lower outside corners of the stock bezel must be transferred to the reproduction bezel, if a reproduction bezel is being used.
3. Place the plastic bezel face down.
4. Place the aluminum gauge panels in place (in the gauge bezel).
5. Place the O-rings around the gauge casings.
6. Place the gauges in desired locations.
7. Secure the assembly mounting panel to the plastic bezel using two 8-32 x 1/2" F-type screws & one sheet metal screw (use one of the 1/8" step Z-clips w/ the step going down on the lower left corner).
8. Secure the right assembly mounting panel to the plastic bezel using an 8-32 x 1/2" F-type screw & a sheet metal screw (use one of the 1/8" step Z-clips w/ the step going up on the lower right corner).
9. Attach the aluminum gauge panels together in the middle using a 10-32 x 3/8" machine screw.
10. Screw four 10-32 x 1" machine screws through the tapped holes in the assembly mounting panels to secure the aluminum gauge panel in the plastic bezel. Do not over tighten.
11. Wire the gauges (refer to instructions provided by gauge manufacturer).



866-248-6356

www.autometer.com

2650-1869-77 12/7/15