




an ISO 9001:2008 Registered Company

# **1959-60 Chevrolet Full-Size/El Camino**

**Condenser Kit *without* Drier**  
**021160**



18865 Goll St. San Antonio, TX 78266 ph: 210-654-7171 fax: 210-654-3113



# Table of Contents




- 1. Cover**
- 2. Table of Contents**
- 3. Packing List/Parts Disclaimer**
- 4. Core Support Measurements**
- 5. Engine Compartment, Mounting Bracket Installation**  
*Figure 1*
- 6. Condenser Installation**  
*Figures 2 & 3*
- 7. Packing List**



**Packing List:**  
**Condenser Kit without Drier (021160)**  
**1959-60 Chevrolet Full-Size/El Camino**

No.	Qty.	Part No.	Description
1.	1	03767-VUC	Parallel Flow Condenser 14" x 24"
2.	1	643092	Bracket, 1959-60 Chevrolet Car, Driver Side Condenser
3.	1	643093	Bracket, 1959-60 Chevrolet Car, Passenger Side Condenser
4.	8	18260-VUB	10-24 Nut with Star Washer
5.	8	18249-VUB	10-24 x 3/8" Pan Head Screw


**\*\* Before beginning installation, open all packages and check contents of shipment.  
Please report any shortages directly to Vintage Air within 15 days. After 15 days,  
Vintage Air will not be responsible for missing or damaged items.**





## Core Support Measurements: 1959-60 Chevrolet Full-Size/El Camino

*This kit was developed based on the measurements below, which were taken from a 1959 Chevrolet core support.*






## Engine Compartment

### Remove the Following:

1. Battery and battery tray.
2. Radiator.
3. Fan shroud.

## Mounting Bracket Installation


1. Install condenser mounting brackets onto condenser using (8) 10-24 x 3/8" pan head screws and (8) 10-24 nuts with star washers as shown in Figure 1, below. **NOTE: Driver side condenser bracket mounts on the 1st and 3rd holes from the left. Passenger side condenser bracket mounts on the 1st and 3rd holes from the right as shown in Figure 1, below.**






## Condenser Installation

1. Install condenser from behind core support as shown in Figure 2, below.
2. Condenser is placed between core support and radiator, and secured with OEM radiator bolts through radiator mounting holes as shown in Figure 3, below.



**Figure 2**



**NOTE: Install condenser assembly between core support and radiator, and secure with OEM radiator bolts.**

**Figure 3**






**Packing List:**  
**Condenser Kit without Drier (021160)**  
**1959-60 Chevrolet Full-Size/El Camino**

No.	Qty.	Part No.	Description	
1.	1	03767-VUC	Parallel Flow Condenser 14" x 24"	_____
2.	1	643092	Bracket, 1959-60 Chevrolet Car, Driver Side Condenser	_____
3.	1	643093	Bracket, 1959-60 Chevrolet Car, Passenger Side Condenser	_____
4.	8	18260-VUB	10-24 Nut with Star Washer	_____
5.	8	18249-VUB	10-24 x 3/8" Pan Head Screw	_____


Checked By: \_\_\_\_\_

Packed By: \_\_\_\_\_


Date: \_\_\_\_\_



2



3



4



5

