



Steering, Brake & Suspension Specialists

#5564DBK - Disc Brake Conversion Instructions for 1955-64 Fullsize GM Cars

Parts:

ROTORS

68-72 Chevelle or GM Equivalent

CALIPERS

79-86 Malibu or GM Equivalent

BEARINGS & SEALS

A-6 Inner bearings

A-2 Outer bearings

7934S Grease seals


Notes:

Read these instructions completely before attempting this conversion.

BEFORE BEGINNING INSTALLATION, MAKE SURE YOUR WHEELS FIT ON THIS CALIPER AND ROTOR. Make sure this kit fits your application before painting or plating. Parts that have been painted, plated or modified may not be returned.

Instructions:

1. Disconnect the brake hoses where they attach to the brake lines at the frame.
2. Remove the drum brake and backing plate assembly so all that remains is the spindle. A piece of 180 grit emery cloth can be used to clean the spindle if necessary. Be sure that the 5/8" threaded hole at the top of the spindle is clean and the threads are in good condition. You may need to use a tap to repair any damaged threads.
3. Using the new hardware supplied with the kit, install the steering arms and caliper brackets to the spindle with the 5/8" bolt through the
4. Pack the wheel bearings with high quality bearing grease. Install the inner bearings and grease seals into the rotors. Install the rotors onto the spindle, then the outer bearings, spindle washers, and the new spindle nuts supplied in the kit. Adjust the wheel bearings as follows:
 - a. Tighten the nut only slightly (no more than 12lb/ft.) spin the rotor in a forward direction to ensure the bearings are fully seated.
 - b. Check that the spindle nut is still tight. If not repeat step a.
 - c. Loosen the spindle nut until it is just loose.
 - d. Hand tighten the spindle nut and install the cotter pin. Do not use a wrench! If necessary loosen the nut too the first position the cotter pin can be installed into.
5. Install the cotter pins (*see note below regarding spindle hardware) followed by the dust caps.



Warning: Stock drum brake wheels may not work with disc brake conversions. Drum brake wheels were not made with disc brakes in mind so there may be wheel to caliper clearance problems. Before installing this kit, make sure your wheels fit the brake assembly.

For those wanting to keep stock wheels that interfere with the installation, there are companies such as Wheelsmith, Stockton Wheel Co. and Wheel Vintiques that can remove the original wheel centers and re-install them into a new disc brake rim. Please call for more information.

Wheelsmith (714) 556-3861 • Wheel Vintiques (209) 251-6957 • Stockton Wheel Service (209) 464-7771

Classic Performance Products, Inc. 714.522.2000 | fax 714.522.2500
175 E. Freedom Avenue | Anaheim, CA 92801 | www.classicperform.com

#5564DBK - Disc Brake Conversion Instructions (con't) *for 1955-64 Fullsize GM Cars*

5. Install the caliper assemblies onto the caliper brackets. The caliper bleed screws will be towards the top of the caliper.
6. Loosely attach the new brake hoses to the calipers. Connect the brake hose to the tab on the frame and, connect the brake line to the brake hose. Tighten both ends of the brake hose.
7. Bleed the brakes.

8. Set the toe before the car is driven.

NOTE: 5/8" I.D. spacer is for use on 1959-64 only. Discard this spacer for 1955-58 applications.

Note Regarding Spindle Hardware:

This spindle hardware kit fits a variety of different applications. In some applications when the slotted nut is installed, the cotter pin hole will be located near the bottom of the slot (*see photo at right*). In these cases, to simplify the installation we suggest putting a slight bend towards the end of the cotter pin to allow it to clear the rotor hub and slide through the nut and spindle assembly. Once the cotter pin is through both sides of the nut, you may need to tap it flush to the slotted nut with a small punch before securing the cotter in place. *See pictures below.*

