

### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



#### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



## 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



# 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509



### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.



### 7/16" BOLTS

Use these special four bolts supplied in the center manifold holes (use thread sealant). Tighten these four first, using a torque wrench and a 7/16" swivel socket or a 7/16" box/open end wrench. If using a box wrench, estimate the torque compared to other bolts.

W509 W509